

To open the filter chamber



Turn over
the Airpura



Remove the 4
retaining screws



Take off
the cover



Remove
the gasket



Position the
Prefilter inside
the filter
chamber




Place a felt gasket at
the bottom of the
filter chamber




Unfold the filter slider
(Supplied with replacement
filters or on request
Part#6F 001)



Roll it
into a spiral



Insert the tube
into the filter
chamber inside
the Prefilter



Let the spiral
open to fill
the opening




Open the top of the
spiral to make a
slight funnel



Insert the
Carbon canister into
the funnel and hold it
straight



Let the canister
slide down
the filter slider



Pull the filter slider up
out of the cavity using
both hands and let the
canister slide to the
bottom of the cavity



Remove the filter
slider and fold it
for further use



Slide in the
Hepa filter

Airpura 
AIR PURIFIERS

F600

OPERATING
&
FILTER REPLACEMENT
DIRECTIONS

To close the filter chamber



Replace
the gasket



Position the
indentation in the cover
into the center of the
HEPA filter



Replace
the 4 screws
and tighten



Turn the Airpura
back on casters

TO BEGIN USING YOUR AIRPURA

Inspect the exterior of your Airpura to verify there is no damage from shipping. If any damage is noted, please follow the instructions from the distributor returns policy.

Wipe the unit with a damp cloth to remove any dust from packaging

Plug the unit into a regular grounded 110 volt outlet

Turn on the unit to MAX and allow it to run for at least 30 minutes

Set the variable speed control to the level you wish

The most efficient way to use your Airpura for regular air quality maintenance is to run it at a low speed **24 hours a day 7 days a week.**

Always maintain a humidity level of 40% or less in your home to ensure the unit is operating at optimal levels. Overly humid conditions can have an adverse effect on the performance of the carbon. When using purifier with a dehumidifier, please keep dehumidifier at least 6 feet away.



FILTER MAINTENANCE AND REPLACEMENT

The Prefilter

Can be vacuumed from the exterior of the unit once a month or more often. Should be replaced at least after 12 months of use

To vacuum the Prefilter

Use the brush attachment on your vacuum cleaner
Vacuum slowly around the mesh surface of the filter chamber

IMPORTANT SAFETY NOTE

Please ensure air purifier is turned OFF when plugging into a power source. Failure to do so may result in motor potentially stalling and/or burning.



Poly Prefilter 600 2-pack
12 months



HEPA 600RVHU filter
(99.97% efficient)
3 to 5 years

F614: HEPA 14 filter
(99.99% efficient)

18 lbs, Impregnated Carbon Filter 35% potassium permanganate carbon, 65% coconut shell
24 months

Technical specifications

Odors, airborne chemical control

18 lbs enhanced Carbon
13"H x 13.25"OD x 9"ID

Particle removal

40 ft² true HEPA
(Measured 1 side only)
7-12 pleats per inch
Pleats warm rolled with separators

Air Flow 560 cfm

More cfm than any other home unit available

Prefilter

570 in² x 1 in

Housing

Powder coat steel

Size

23 in x 15 in

Weight

45 lbs total

Watts


120 on high / 40 on low

Sound Level at 6 feet

34.2 db on low
57.2 db on high
(Room Level 25.1)

Possible upgrade :

UV Germicidal Lamp, 20 Watt



Air purifiers models and filter configurations

	Prefilter	Particulate
Alternates	Cotton Prefilter TarBarrier Prefilter	
Upgrade		HEPA 14 filter (99.99% efficient @ 0.3 microns) ULPA filter (99.9999% efficient @ 0.1 microns)